## The AArch64 processor (aka arm64), part 10: Loading constants

devblogs.microsoft.com/oldnewthing/20220808-00

August 8, 2022



Since AArch64 uses fixed-size 32-bit instructions, you have to exercise some creativity to load a 64-bit constant.

```
; move wide with zero
; Rd = imm16 << n
; n can be 0, 16, 32, or 48
movz Rd, #imm16, LSL #n
; move wide with not
; Rd = ~(imm16 << n)
; n can be 0, 16, 32, or 48
movn Rd, #imm16, LSL #n
; move wide with keep
; Rd[n+15:n] = imm16
movk Rd, #imm16, LSL #n
```

The MOVZ instruction loads a 16-bit unsigned value into one of the four lanes of a 64-bit destination, or one of the two lanes of a 32-bit destination. All the remaining lanes are set to zero.

The MOVN instruction does the same thing as MOVZ, except the whole thing is bitwise negated. (Be careful not to confuse MOVN with MVN.)

The MOVK instruction does the same thing as MOVZ, except that instead of setting the other lanes to zero, the other lanes are left unchanged.

Loading a 32-bit value can be done in two instructions by using MOVZ to load 16 bits into half of the register, than the MOVK into the other half.

movzr0, #0x1234; r0 = 0x00001234movkr0, #0xABCD, LSL #16; r0 = 0xABCD1234

This technique can be extended to load a 64-bit value in four steps, but that's getting quite unwieldy. The compiler is more likely to store the value in the code segment and use a *pc*-relative addressing mode to load it.

```
; special syntax for pc-relative loads
ldr x0, =0x123456789ABCDEF0 ; load 64-bit value
ldr w0, =0x12345678 ; load 32-bit value
```

As I noted in the discussion of addressing modes, the assembler and disassembler use this special equals-sign notation to represent a *pc*-relative load. It means that the value is stored in a *literal pool* in the code segment, and a *pc*-relative load is being used to fetch it. The assembler batches up all of these literals and emits them between functions. The *pc*-relative load has a reach of  $\pm 1$ MB, so you are unlikely to run into the problem that you had on AArch32, where the reach was only  $\pm 4$ KB, and you had to find a safe place to dump the literals in the middle of the function.

There are quite a number of instructions that generate constants, and if you use the MOV pseudo-instruction, the assembler will try to find one that works.

; load up a constant somehow mov Rd, #imm

Instruction	Used for
add Rd, zr, #imm12	0×0000000`0000XXX
add Rd, zr, #imm12, LSL #12	0×0000000`00XXX000
<pre>sub Wd, wzr, #imm12</pre>	0x0000000`FFFFXXX
sub Wd, wzr, #imm12, LSL #12	0x0000000`FFXXXFFF
<pre>sub Xd, xzr, #imm12</pre>	0xFFFFFFF`FFFFXXX
sub Xd, xzr, #imm12, LSL #12	0xFFFFFFF`FFXXXFFF
movz Rd, #imm16	0×0000000`0000XXXX
movz Rd, #imm16, LSL #16	0×0000000`XXXX0000
movz Rd, #imm16, LSL #32	0×0000XXXX`0000000
movz Rd, #imm16, LSL #48	0×XXXX0000`0000000

movn Wd, #imm16	0x0000000`FFFFXXXX
mo∨n Wd, #imm16, LSL #16	0x0000000`XXXXFFFF
movn Xd, #imm16	0xFFFFFFF`FFFXXXX
movn Xd, #imm16, LSL #16	0xFFFFFFF`XXXXFFFF
movn Xd, #imm16, LSL #32	0xFFFFXXXX`FFFFFFF
movn Xd, #imm16, LSL #48	0xXXXXFFFF`FFFFFFF
orr Xd, xzr, #imm	Value can be expressed as a Bitwise operation constant
orr Wd, wzr, #imm	Value can be expressed as lower 32 bits of a Bitwise operation constant

A common type of sort-of constant is the address of a global variable. It's a constant whose value isn't discovered until runtime. We'll look at those next time.

Raymond Chen

Follow

